REMOTE CONTROL


SUBSCRIPTION/ASSOCIATION/ACTIVATION AND USAGE

This user guide will explain the path that you need to follow to activate Remote Control for your car.

First of all, to use Remote Control, you need a MYPEUGEOT account and register your car. If you haven't installed the mobile app on your smartphone, you can easily do it by downloading the app from Google Play Store or App Store.



Once you've downloaded MYPEUGEOT app, open and visit the Services store section, select "Discover" to activate Remote Control. Tap on "START ACTIVATION" and follow a few steps to activate your new service.




You will be redirected to the Service Activation page to learn about Remote Control and the benefits that will be available to you. Scroll down and tap on the "GET" button to continue activating the service.

To activate Remote Control, it is important to read and accept the General Conditions. After saving your preferences, you can start the activation process through the Mobile App, just tapping on "CONTINUE TO MYPEUGEOT".


There are only 3 steps to follow before you can start to enjoy your Remote Control. Before initiating the activation, confirm that you have already read and accepted the terms and condition, then press "Start".




1. Enter your phone number and enter the 6-digits code that you received via SMS



2. Create your personal 4-digits Safety Code. To start this step, you will receive a 9-digits code via SMS. Insert the 9-digits code and then proceed to create your Safety Code. This code will allow you to secure remote access to your car and to use the Remote Control features.



3. Connect your mobile phone to your vehicle using Bluetooth. Start your vehicle and turn on Bluetooth on your mobile phone, then click on "PAIR" to start the association.



Now the Remote Control Service is activated: you may be asked to update your vehicle equipment software to fully enjoy all the features and manage your car remotely.

HOW TO USE YOUR REMOTE CONTROL:

Once you have activated Remote Control, you can lock and unlock the doors, or turn on the light and the horn with a few simple steps.

To remotely control your car, open "MYPEUGEOT" app, select the icon of the command that you would like to send to your vehicle, confirm the action and wait for a few seconds. Remember that each 7 days you need to confirm the remote commands using your safety code.

